

The Audality S7 Wireless Speaker

The S7 Wireless Speaker System is a highly portable, high-fidelity wireless speaker and transmitter combo for playing music from a computer or phone directly to up to 4 Audality speakers. The S7 speaker has a 10-inch speaker and tweeter, a built-in 225-watt amplifier, rechargeable lithium-ion battery with enough battery to run for an entire weekend on a charge. When used with additional S7 speakers or other Audality compatible speakers, it can be set up as left or right channel to create a multi-speaker stereo setup.



High Fidelity sound, literally anywhere in the world.

It's time to stop settling for Bluetooth or Wi-fi wireless. You deserve better, which is why Audality created the solution. Audality wireless audio is the only audio technology that offers portability and consistent, uncompressed HD sound anywhere in the world.

Sophisticated technology, made simple.

Audality wireless technology provides all the functionality needed in a high-fidelity home audio system, with a quick and simple set up. Simply turn on your speaker, pair with the transmitter, and enjoy consistent HD sound on up to four speakers, no Bluetooth or Wi-Fi needed.

Extremely portable and unbeatable battery life

Audality high-quality Class-D amplifiers create the purest sound quality in a highly efficient package for portable, long-lasting battery operation. The audio quality from our amplifiers is unmistakably superior to any wireless speaker you've ever heard. They deliver true audiophile sound quality without the astronomical price tag.

Handcrafted to perfection

Our home audio speakers are hand-crafted out of bamboo for a beautiful, natural cabinet that looks amazing with any decor. You'll want to display them prominently like a piece of art.

Environmentally friendly and sustainable

Audality is committed to creating sustainable and environmentally friendly products. Audality speaker cabinets are manufactured from bamboo, and our amplifiers are up to four times as efficient as other amplifiers, so they run for hours, even days, on a single charge.

SPECIFICATIONS

SPECIFICATIONS	
System Description	S7 Loudspeaker with HD Audio Transmitter
Frequency Response	20Hz-20kHz, +/- 4dB
Maximum Output (SPL)	121 dB @ 1m
Power	225W continuous (class D)
Drivers (each speaker)	10" weather resistant 8-ohm speaker 6" weather resistant 8-ohm speaker 4" ribbon tweeter
Enclosure Material	Beautiful bamboo, 12mm thick
Inputs	Auxiliary audio input (3.5mm stereo)
Transmission Range	Up to 100 meters Superior wall penetration
Dimensions	Height: 24.25" (61.6mm) Base: 14" x 10" (35.6mm x 25.4mm) Top: 11.25" x 8.25" (28.6mm x 21.0mm)
Weight	24.25 lbs. (11.0 kg.)
Battery Information	6,000mAh rechargeable lithium ion battery 20+ hours of battery life per charge Battery life gauge on cabinet rear panel Full charge in 2 hours from empty
Connectivity Information	Simple one-touch connectivity Automatic radio channel selection
Certifications	FCC, Europe, Industry Canada, Australia/NZ
Included Accessories	Wall Charger (24V) USB-A HD audio transmitter iOS or Android phone adapter